







Note:
Upper and lower tool holders are different.
The 2 holes marked by arrows at left are smaller and this the lower holder

Step 1:

Locate one support foot and the lower tool holder.
Set screws on the lower tool holder should fit in the appropriate hole in the support footing. Next, screw on thumb nuts be careful not to over tighten.

Step 2:

Do the same as step one for the upper tool holder and lower support

Step 3:

Locate other support foot and align set screws. Next, use the thumb nuts to complete the tool holder. Also being careful not to over tighten

Note:

If tool holder seems tweaked when set on a flat surface loosen all thumb nut and re-tighten.

This should take car of the issue. Again making note not to over tighten the thumb nuts.

Call or E-mail with Questions
507-828-8697 - brandon.skewes@skewesjewelry.com
www.genesisrcp.com